
Lifthor Mischir Ewo

User's Manual

by Thor's Drone World



Content:

Tablet clamp

Compatible with 7.9" up to





Thumb

Screws (x2)





Hex Key (x2)

How to assemble:

Remove the components from the box, use the bigger hex key provided to unscrew the ball joint from the box inlay.







Attach the stopper to the RC with one of the thumb screws provided.



Gently lower the RC into the bay of the base with a slight inclination.





Make sure the RC is centered and aligned properly



Unscrew the tightening ring from the back of the Tablet Clamp and place it on the ball joint





The clamp has two mechanisms to ensure your tablet sit secure and in place.

The first mechanism is the ratchet part, to adjust to the size of your tablet. We recommend setting it a little smaller (1" / 2.5cm) than the actual size of the table for a tighter, secure fit.

Once you have selected the right height look he ratchet in place by sliding the lock downwards.



Place the tablet in landscape mode by pulling the spring mechanism upwards and release it to secure the tablet in place. You can adjust the top clamp brackets, if needed, to avoid pressing on any buttons



Compatible with most small tablets like iPad Mini or similar up to larger tablets like the iPad Pro 12.9" and everything in between



Alternative setup



without support plate



with support plate

Installation of support plate

Start by connecting the cable to the RC



Thread the cable through the top of the hole from the support plate

Secure the support plate to the main body with the thumb screw provided

LIFTHOR TO



Separately sold accessories:





Mounting bracket for CrystalSky Monitor

www.lifthor.com

